

CAN-BUS INTERFACE

Car model	Construction Year	Position selectors (see page 9)		REV.
		1	2	
Alfa Romeo				
147 (Engine Can Bus)	2007 →	1	9	20
159	2005 →	1	9	20
Brera	2006 →	1	9	20
Giulietta	2010 →	1	6	20
Mito	2008 →	1	8	20
Spider	2006 →	1	9	20
Audi				
A1	2010 →	3	B	20
A3	2003 - 2010	3	A	20
A3 Sportback	2004 - 2010	3	A	20
A3	2010 →	3	B	20
A3 Sportback	2010 →	3	B	20
A4	2004 - 2007	3	8	20
A4	2008 →	3	9	20
A5	2007 →	3	9	20
A6	2005 - 2010	3	D	20
A6	2010 →	3	D	20
A7	2010 →	3	4	20
A8	2006 - 2009	3	D	20
A8	2009 →	3	4	20
Q3	2011 →	3	B	23
Q5	2008 →	3	9	20
Q7	2006 →	3	D	20
R8	2007 →	3	A	20
S5	2007 →	3	9	20
TT	2006 - 2010	3	A	20
TT	2010 →	3	B	20
BMW				
Serie 1	2004 - 2011	7	0	20
Serie 1 (I. Key)	2004 - 2011	2	0	20
Serie 1	2011 →	7	1	20
Serie 1 (I. Key)	2011 →	7	2	20
Serie 3	2004 - 2010	7	0	20
Serie 3 (I. Key)	2004 - 2010	2	0	20
Serie 3	2010 →	7	1	21
Serie 3 (I. Key)	2010 →	7	2	21
Serie 5	2003 - 2010	7	0	20
Serie 5 (I. Key)	2003 - 2010	2	0	20
Serie 5	2010 →	7	1	20
Serie 5 (I. Key)	2010 →	7	2	20
Serie 6	2011 →	7	1	20
Serie 6 (I. Key)	2011 →	7	2	20
Serie 7	2011 →	7	1	20
Serie 7 (I. Key)	2011 →	7	2	20
X1	2010 →	7	0	20

CAN-BUS INTERFACE

Car model	Construction Year	Position selectors (see page 9)		REV.
		1	2	
X1 (I. Key)	2010 →	2	0	20
X3	2010 →	7	1	20
X3 (I. Key)	2010 →	7	2	20
X5	2007 →	7	0	20
X5 (I. Key)	2007 →	2	0	20
X6	2007 →	7	0	20
X6 (I. Key)	2007 →	2	0	20
Mini	2007 →	7	0	20
Mini (I. Key)	2007 →	2	0	20
Mini Countryman	2010 →	7	0	20
Mini Countryman (I. Key)	2010 →	2	0	20
Chevrolet				
Aveo	2011 →	3	2	23
Captiva	2006 →	4	8	20
Cruze	2009 →	3	2	20
Orlando	2011 →	3	2	23
Chrysler				
300C	2003 - 2008	E	0	22
Grand Voyager	2008 - 2010	E	2	22
PT Cruiser	2007 →	E	0	22
Citroën				
Berlingo	2008 →	2	9	20
C2	2005 →	2	9	20
C3	2005 - 2010	2	9	20
C3	2010 →	2	9	22
C4	2005 - 2010	2	9	20
C4	2011 →	C	0	21
C4 Picasso	2007 →	2	9	20
C5	2004 - 2007	2	9	20
C5	2008 →	2	9	20
New C5	2008 →	2	9	21
C8	2006 →	2	9	20
C-Crosser	2008 →	2	7	20
DS3	2010 →	2	9	20
Jumper	2006 →	2	1	20
Jumpy	2006 →	2	9	20
Nemo	2008 →	1	8	20
Dodge				
Caliber	2006 - 2011	E	0	22
Journey	2008 - 2011	E	2	22
Nitro	2007 - 2011	E	2	22
Ram	-	E	0	22
Ferrari				
Scaglietti	2004 →	2	2	20
Fiat				
Bravo 2	2007 →	2	3	20

CAN-BUS INTERFACE

Car model	Construction Year	Position selectors (see page 9)		REV.
		1	2	
Cinquecento / 500	2007 →	1	8	20
Croma	2005 →	2	3	20
Cubo	2010 →	1	8	20
Doblo (Engine Can Bus)	2005 - 2009	2	3	20
Doblo	2009 →	1	8	20
Ducato	2006 -2011	2	1	20
Ducato	2011 →	1	6	21
Fiorino	2008 →	1	8	20
Freemont	2011 →	E	5	22
Idea	2003 - 2008	2	2	20
Idea	2008 →	2	3	20
Linea	2007 →	2	3	20
Panda	2003 →	2	3	20
Grande Punto	2005 - 2009	1	8	20
Grande Punto	2009 →	1	8	20
Punto Evo	2009 →	1	8	20
Qubo	2008 →	1	8	20
Scudo	2007 →	2	9	20
Sedici (I. Key)	2006 →	A	0	21
Stilo	2001 - 2005	2	2	20
Stilo	2006 →	2	3	20
Ford				
C-max	2003 - 2010	1	1	20
C-max	2010 →	1	5	20
C-max (I. Key)	2010 →	1	4	20
Fiesta	2006 - 2008	1	2	20
Fiesta	2008 →	1	3	20
Fiesta (I.Key)	2008 →	A	C	22
Focus	2005 - 2011	1	1	20
Focus	2011 →	1	5	20
Focus (I. Key)	2011 →	1	4	20
Fusion	2006 →	1	2	20
Ka	2008 →	1	8	20
Kuga	2008 →	1	1	20
Mondeo	2007 - 2010	4	0	20
Mondeo	2010 →	4	0	21
Mondeo (I. Key)	2010 →	1	A	20
S-Max	2011 →	4	0	20
S-Max (I. Key)	2011 →	1	A	20
Transit (Engine Can Bus)	2006 →	0	2	23
Turneo (Engine Can Bus)	2006 →	0	2	23
Turneo connect	2010 →	A	A	21
Transit connect	2010 →	A	B	21
Honda				
Accord	2005 - 2008	4	B	20
Accord	2008 →	4	C	20

CAN - BUS INTERFACE

Car model	Construction Year	Position selectors (see page 9)		REV.
		1	2	
Civic	2006 →	4	A	20
Civic Hybrid	2007 →	4	A	20
Cr-v	2006 →	4	A	20
Insight	2009 →	4	A	20
Jazz	2009 →	4	A	20
Pilot	2008 →	4	D	20
Hyundai				
Elantra OEM Alarm	2010 →	B	8	22
Elantra OEM Alarm (Engine Can Bus)	2010 →	D	F	23
Genesis Coupe (Engine Can Bus)	2010 →	D	F	23
H1 (Engine Can Bus)	2011 →	D	F	23
I40	2011 →	B	3	22
I40 OEM Alarm	2011 →	B	4	22
I40 (Engine Can Bus)	2011 →	D	F	23
IX20	2010 →	B	7	22
IX20 (Engine Can Bus)	2010 →	D	F	23
IX35	2010 →	B	0	21
IX35 OEM Alarm	2010 →	B	1	22
IX35 (Engine Can Bus)	2010 →	D	F	23
Santafe (Engine Can bus)	2006 →	D	F	23
Solaris	2011 →	B	A	22
Solaris (Engine Can Bus)	2011 →	D	F	23
Infiniti				
EX35	2008 →	3	6	20
FX35	2006 →	1	E	20
G35	2006 →	1	C	20
MX35X	2006 →	1	D	20
QX (I. Key)	2011 →	3	1	23
Iveco				
Daily	2006 →	2	1	20
Jeep				
Commander	2006 →	E	0	22
Compass	2007 →	E	0	22
Cherokee	2008 →	E	0	22
Grand Cherokee	2005 - 2010	E	0	22
Grand Cherokee	2010 →	E	4	23
Patriot	2007 →	E	0	22
Wrangler	2007 →	E	2	23
Kia				
Carnival (Engine Can Bus)	2006 →	D	F	23
Cerato (Engine Can Bus)	2010 →	D	F	23
Magentis (Engine Can Bus)	2009 →	D	F	23
Mohave (Engine Can Bus)	2009 →	D	F	23
Rio (Engine Can Bus)	2010 →	D	F	23
Sorento	2009 →	D	3	22
Sorento (engine Can Bus)	2009 →	D	F	23

CAN-BUS INTERFACE

Car model	Construction Year	Position selectors (see page 9)		REV.
		1	2	
Sportage	2010 →	D	0	22
Sportage (Engine Can Bus)	2010 →	D	F	23
Sportage OEM Alarm	2010 →	D	1	22
Venga (Engine Can Bus)	2010 →	D	F	23
Lancia				
Delta	2008 →	2	3	20
Musa	2004 - 2007	2	2	20
Musa	2007 →	2	3	20
Ypsilon	2003 - 2006	2	2	20
Ypsilon	2006 - 2011	2	3	20
Ypsilon	2011 →	1	8	21
LandRover				
Discovery 4	2010 →	6	2	20
Freelander 2	2007 →	6	1	20
Range Rover Sport	2006 - 2010	6	0	20
Range Rover Sport	2010 →	6	2	20
Lexus				
CT	-	4	4	21
GS	2008 →	4	4	20
IS	2005 →	4	4	20
LS	2006 →	4	9	20
LX	2007 →	2	5	20
Mazda				
2	2006 →	8	1	20
3	2009 →	8	1	20
6	2008 →	8	2	20
CX-7	2007 →	8	0	21
MPV	2004 -2006	8	0	20
Mercedes				
A (w169)	2005 →	5	2	20
B (w245)	2005 - 2010	5	2	20
B (w246)	2011 →	5	4	23
C (w203)	2003 - 2007	5	1	20
C (w204)	2007 →	5	4	20
CL (w216)	2007 →	5	4	23
CLC	2008 →	5	1	21
CLK (w209)	2003 →	5	1	20
CLS (w219)	2008 - 2010	5	1	20
CLS (w218)	2010 →	5	4	22
E (w211)	2003 - 2009	5	1	20
E coupé (w207)	2009 →	5	4	20
E (w212)	2009 →	5	4	20
GL (w164)	2006 →	5	2	20
GLK (x204)	2009 →	5	4	20
ML (w164)	2005 - 2012	5	2	20
ML (w166)	2012 →	5	4	23

CAN-BUS INTERFACE

Car model	Construction Year	Position selectors (see page 9)		REV.
		1	2	
R (w251)	2006 →	5	2	20
Viano (w157)	2004 →	5	1	20
Vito (w157)	2004 →	5	1	20
S (w221)	2007 →	5	4	20
SLK (w171)	2004 - 2010	5	1	20
SLK (w172)	2011 →	5	4	20
Sprinter	2006 →	5	2	20
Mitsubishi				
Outlander	2007 →	2	7	20
ASX	2010 →	2	7	20
Nissan				
Evalia	2011 →	4	1	23
Juke	2010 →	4	7	20
Juke (I. Key)	2010 →	3	1	20
Micra	2003 - 2010	4	1	20
Micra (I. Key)	2003 - 2010	3	F	20
Micra	2010 →	4	7	21
Micra (I. Key)	2010 →	3	1	21
Murano (I. Key)	2008 - 2010	3	5	20
Murano (I. Key)	2010 →	3	5	20
Navara	2007 →	4	7	20
Navara (I. Key)	2007 →	3	F	20
Note	2006 →	4	1	20
Note (I. Key)	2006 →	3	F	20
NV200	2011 →	4	1	23
NV400	2011 →	9	B	23
Qashqai	2007 →	4	7	20
Qashqai (I. Key)	2007 →	3	F	20
Teana (I. Key)	2008 →	3	6	20
Tiida	2007 →	4	1	20
Tiida	2007 →	3	F	20
X-Trail	2007 →	4	7	20
X-Trail (I. Key)	2007 →	3	F	20
Pathfinder	2006 →	4	7	20
Pathfinder (I. Key)	2006 →	3	F	20
Patrol	2010 →	4	7	20
Patrol (I. Key)	2010 →	3	5	20
Primastar (Engine Can Bus)	2005 →	F	0	23
Opel				
Antara	2007 →	4	8	20
Astra	2010 →	3	2	21
Astra H	2004 - 2010	4	2	20
Astra H (R.E.C.) *	2004 - 2010	4	5	20
Astra H (R.E.C. + I. Key) *	2004 - 2010	4	3	21
Corsa D	2006 →	4	6	20
Insignia	2009 →	3	2	20

CAN-BUS INTERFACE

Car model	Construction Year	Position selectors (see page 9)		REV.
		1	2	
Meriva	2010 →	3	2	20
Movano	2011 →	9	B	23
Signum	2003 →	4	5	20
Signum (R.E.C.) *	2003 →	4	5	21
Vectra	2002 →	4	5	20
Vectra (R.E.C.) *	2002 →	4	5	21
Vivaro (Engine Can Bus)	2005 →	F	0	23
Zafira	2005 →	4	2	20
Zafira (R.E.C.) *	2005 →	4	5	20
Zafira (R.E.C. + I. Key) *	2006 →	4	3	21
Zafira Tourer	2011 →	3	2	21
Peugeot				
207	2006 →	2	9	20
307	2005 →	2	9	20
308	2007 →	2	9	20
407	2004 →	2	9	20
508	2010 →	2	B	21
807	2008 →	2	9	20
3008	2009 →	2	9	20
4007	2008 →	2	7	20
5008	2009 →	2	9	20
Bipper	2008 →	1	8	20
Boxer	2006 - 2011	2	1	20
Boxer	2011 →	1	7	21
Expert	2006 →	2	9	20
Partner	2008 →	2	9	20
RCZ	2010 →	2	6	21
Porsche				
997	2006 →	0	9	20
Cayenne	2003 - 2006	1	0	20
Cayenne	2006 - 2010	3	E	20
Cayenne	2010 →	2	F	20
Cayman	2005 →	0	9	20
Renault				
Clio	2007 →	9	B	20
Fluence	2010 →	9	A	20
Kangoo	2008 →	9	B	20
Laguna	2007 →	9	A	20
Laguna Coupe	2008 →	9	A	20
Laguna Sport tourer	2007 →	9	A	20
Master	2010 →	9	B	20
Megane	2008 →	9	A	20
Megane Coupe	2008 →	9	A	20
Megane Sport tourer	2009 →	9	A	20
Scenic	2009 →	9	A	20
Scenic X-Mod	2009 →	9	A	20

CAN-BUS INTERFACE

Car model	Construction Year	Position selectors (see page 9)		REV.
		1	2	
Traffic (Engine Can Bus)	2005 →	F	0	23
Seat				
Alhambra	2010 →	3	B	20
Altea	2004 - 2009	3	A	20
Altea	2009 →	3	B	20
Altea XL	2004 - 2009	3	A	20
Altea XL	2009 →	3	B	20
Cordoba	2005 →	3	C	20
Exeo	2009 →	3	8	20
Ibiza	2002 - 2008	3	C	20
Ibiza	2008 →	3	7	20
Leon	2005 - 2009	3	A	20
Leon	2009 →	3	B	20
Toledo	2005 →	3	A	20
Skoda				
Fabia	2007 - 2011	3	C	20
Fabia	2011 →	3	0	23
Octavia	2005 - 2008	3	B	20
Octavia	2009 →	3	B	20
Roomster	2006 - 2011	3	C	20
Roomster	2011 →	3	0	23
Superb	2002 - 2008	B	5	20
Superb	2008 →	3	B	20
Yeti	2009 →	3	B	20
Suzuki				
SX4	2006 →	A	0	21
Grand Vitara	2006 →	A	0	21
Swift	2005 - 2010	A	0	21
Swift (I. Key)	2010 →	A	1	21
Swift	2010 →	A	2	21
Toyota				
Auris	2007 →	2	4	20
Avensis	2009 →	2	4	20
Camry	2005 →	2	4	20
Corolla Sedan	2006 →	2	4	20
IQ	2009 →	2	4	20
Land Cruiser	2008 →	2	4	20
Prius	2009 →	2	4	20
Rav4	2006 →	2	4	20
Urban Cruiser	2009 →	2	5	20
Verso	2009 →	2	4	20
Yaris	2006 →	2	4	20
Volkswagen				
Amorok	2010 →	3	0	20
Caddy	2004 - 2010	3	B	20
Caddy	2010 →	3	B	20

CAN-BUS INTERFACE

Car model	Construction Year	Position selectors (see page 9)		REV.
		1	2	
California	2010 →	3	0	20
Caravelle	2010 →	3	0	20
Crafter	2006 →	5	2	20
Eos	2006 →	3	B	20
Golf 5	2003 - 2008	3	B	20
Golf 5 Plus	2005 - 2008	3	B	20
Golf 5 Variant	2007 →	3	B	20
Golf 6	2008 →	3	B	20
Golf 6 plus	2008 →	3	B	20
Jetta	2005 →	3	B	20
Multivan	2010 →	3	0	20
Passat B5	1999 - 2005	B	5	20
Passat B6	2005 - 2010	3	A	20
Passat CC	2008 →	3	A	20
Passat	2011 →	3	0	20
Polo	2005 - 2009	3	C	20
Polo	2009 - 2011	3	7	20
Polo Sedan	2010 →	3	3	20
Polo	2011 →	3	0	20
Scirocco	2008 - 2010	3	B	20
Scirocco	2010 →	3	B	20
Sharan	2010 →	3	B	20
Touareg	2006 - 2010	3	E	20
Touareg	2010 -2012	3	4	20
Touareg	2012 →	3	4	20
Touran	2003 - 2010	3	B	20
Touran	2010 →	3	B	20
Tiguan	2007 - 2010	3	B	20
Tiguan	2010 →	3	B	20
Transporter T5	2006 - 2010	3	C	20
Transporter T5	2010 →	3	0	20
Volvo				
C30	2008 →	9	0	20
C70	2006 →	9	0	20
S40	2006 →	9	0	20
S60	2006 - 2010	9	1	20
S60	2010 →	9	3	20
S80	2007 →	9	2	20
V50	2006 →	9	0	20
V70	2008 →	9	2	20
XC60	2008 →	9	2	20
XC70	2008 →	9	2	20
XC90	2006 →	9	1	20

CAN-BUS INTERFACE

Car model	Construction Year	Position selectors (see page 9)		REV.
		1	2	

NIEUW - NOUVEAU - NEW

- * **R.E.C.:** Voertuig met "Rear Electrical Center (elektrische centrale in koffer)
Véhicule avec "Rear Electrical Center" (centrale électrique dans le coffre)
Vehicle with "Rear Electrical Center" (electrical center in trunk)

Position selectors

