




# Installation Guide

Part No: CTSMT004.2 Mitsubishi Steering Wheel Control Interface



## Vehicle Compatibility:

Mitsubishi

Colt 2008 >

Non Amplified Systems

## Steering Wheel Control Functions



Volume +  
Volume -



Seek/Track+  
Seek/Track-

Source

\* Note All Dates are guide lines only as specifications of vehicles change


# Installation Guide

Part No: CTSMT004.2 Mitsubishi Steering Wheel Control Interface

## Trip Computer Settings

The trip computer can be accessed through the steering wheel controls.

Press  once briefly for source

Press  for 2 Seconds to cycle through trip computer settings. Each 2 second push will enter the next trip computer screen

Press  and hold to reset on any trip computer screen

