



PEUGEOT 306
Phase 1 02/1993→02/1997
Phase 2 03/1997→02/2002



04/1993→08/1999 ISO 10 voies 4 fonctions : SXPG01--





08/1999→06/2001 Mini ISO JAUNE 4 fonctions : SWPG04—



-▲	Man. Freq + CD(C): Track +	Preset + CDC: Disc +
+▼	Man. Freq - CD(C): Track -	Preset - CDC: Disc -

	Volume +	
	Volume -	

08/1999→12/2001 Connecteur NOIR-Bleu sous le colonne de direction 6 fonctions : SXPG03



KEY	Short press	Long press
	Volume +	
	Volume -	
	Man. Freq. + CD(C): Track +	Preset + CDC: Disk +
	Man. Freq. - CD(C): Track -	Preset - CDC: Disk -
CHANGE	FM1→FM2→FM3→LW/MW	
MODE	Source	Mute